

FIG. 1




FIG. 2




FIG. 3




FIG. 4




FIG. 5A



520



RSEL	ENB	OUT	FUNCTION
0	0	TRISTATED	DRIVER DISABLED AND TRISTATED
0	1	TRISTATED	DRIVER DISABLED AND TRISTATED
1	0	TRISTATED	DRIVER ENABLED AND TRISTATED
1	1	IN	DRIVER ENABLED AND DRIVING